

Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

PARTS INCLUDED: 2 – Side Assemblies, 1 – Seat, 1 – Back Stretcher (1 3/4" x 15 7/8"), 2 – Seat Skirts w/pocket holes (2 5/8" x 15 3/4"), 1 - Front Stretcher (2 5/8" x 15 3/4"), 3 – Back Supports (2 5/8" x 14 5/8"), (Opt) 2 – Arm Assemblies

HARDWARE INCLUDED: 10 – 1 1/2" Pan Head and 10 – 2" Countersunk Head Stainless Steel Screws



STEP 1: Lay all pieces on smooth, soft surface, such as cardboard, to avoid scratching.



SIDE ASSEMBLY



SEAT ASSEMBLY



14 5/8" LONG

BACK SUPPORTS



15 3/4" LONG

BACK AND FRONT STRETCHERS, AND (2) SEAT SKIRTS



OPTIONAL ARMS

STEP 2: (a) Use a soft hammer (if necessary) to insert Back Supports and Stretchers in to Side Assembly. (b) Place the other Side Assembly on top of the Back Supports and Stretchers, starting at the top, use a soft hammer (if necessary) to seat the Side Assembly onto the Back Supports and Stretchers making sure that it is tight. (c) Secure the Side Assembly to the Stretchers using (3) – 2" screws. Flip chair over and secure the other side using (3) – 2" screws.



(a)



(b)



(c)

STEP 3: (OPT ARMS) (a) Fasten the Arm Assembly to the back leg thru the pocket hole in the Arm Assembly into the predrilled hole in the leg using 1 – 1 ½” screw. (b) Line the top of the arm support up with the top of the side seat skirt and (c) secure with 2 – 2” screws thru the predrilled holes. (x2)



(a)



(b)



(c)

STEP 4: (a) Place the seat onto the chair base being sure to have the pocket holed side down. Push the seat all of the way up against the back legs. (b) Center the front of the seat and then secure it to the seat skirts with 8 – 1 ½” screws thru the pocket holes in the seat skirts (**DO NOT OVER TIGHTEN**).



(a)



(b)

STEP 5: Enjoy your new Acadia Chair



Arm Chair



ecwoutdoorfurniture.com



Side Chair