

# Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

## LIBERTY ADIRONDACK

### Tools Needed

Cordless Drill

6" #2 Square Drive Bit

5/32" Allen Wrench



**STEP 1:** Lay all pieces on smooth, soft surface, such as cardboard, to avoid scratching. **Be careful to not over tighten any of the fasteners.**



**STEP 2:** (a) Remove the foot rest from the seat assembly and place it to the side to reinstall after your chair is assembled. (b) **(x2)** Place the 2 - 3" stainless steel flat head screws in the seat assembly thru the predrilled holes in the footrest slide and line up with the predrilled holes in the leg assembly (making sure that the bottom of the leg is angled towards the front of the seat assembly) and then secure it. (c) **(x2)** Place the 2" stainless steel flat head screw in the back leg above the footrest slide and then secure it. (d) **(x2)** Place the front leg spreader into the mortise in the front leg and secure it with 2 - 1 1/2" stainless steel pan head screws (flip assembly over and repeat for the other side).



(a)



(b)



(c)



(d)

**STEP 3:** (e) (x2) Line up the side of the bottom back support with the outside of the back leg and up against the notch in the back leg then secure it thru the predrilled holes with 2 – 2" stainless steel flat head screws.(f) (x2) Place a 3 ½" stainless steel allen head lag thru the predrilled hole in one of the arms and line it up with the predrilled hole in the middle back support and secure. (g) Reinstall the footrest and relax in your new Liberty Adirondack chair.



(e)



(f)



(g)



(h)

