

# Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

## BALCONY BAR STOOL

### Tools Needed

Cordless Drill

6" #2 Square Drive Bit



(a)

**STEP 1:** (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**

**STEP 2:** (b) (x2) Insert the seat skirts (pocket hole in the middle) and footrests in to the mortises in one side assembly and fasten with the 1 ½" stainless steel round head screws provided. (c) Place the other side assembly face down and rotate the subassembly on to it then insert the seat skirts and footrests in to the mortises in the side assembly and fasten with the 1 ½" stainless steel round head screws provided.



(b)



(c)

**STEP 3:** (d) Line the bar stool top up by placing the top of the legs into the mortises in the bottom of the bar stool top. (e) Fasten the bar stool top thru the screw pockets using the 1 ½" round head stainless steel screws provided.



(d)



(e)

