

# Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

## CALISTOGA CHAIR

### Tools Needed

Cordless Drill

6" #2 Square Drive Bit



**STEP 1:** (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**



(a)

**STEP 2:** (b) Place one of the side assemblies on a clean soft surface with the mortised holes facing up (c) Insert the seat assembly into the mortised holes (front & back). You may need to use a soft hammer to seat these completely.



(b)



(c)

**STEP 3:** (d) Fasten the front and back seat skirts to the side assemblies using the 1 ½" stainless steel round head screws provided. (e) Fasten the side seat skirt to the side assembly thru the pre drilled holes using the 1 ½" stainless steel round head screws provided. Repeat the process on the other side.



(d)



(e)

**STEP 4:** (f) Chairs with arms come with a pre drilled hole in the front legs with the arms for a 2" stainless steel flat head screw that is provided.



(f)

**STEP 5:** (g) The side assemblies have pre drilled holes to help align the chair back. (h) Place the chair back assembly on top of the seat assembly using the notch in the bottom of the chair back post to locate it and then fasten it using the 1 3/4" stainless steel flat head screws provided thru the pre drilled holes in the chair back post into the pre drilled holes in the side assembly. Repeat the process on the other side.



(f)



(g)

**STEP 6 FOR MULTIPLE UNITS:** (i) Secure the units together using the supplied hook and loop fastener. (j) For a more permanent setup use the 1 3/4" stainless steel flat head screws provided thru the pre drilled holes in the chair leg below the front and back seat skirt into the pre drilled holes in the other chair leg.



(i)



(j)

