

# Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

## CALISTOGA OTTOMAN

### Tools Needed

Cordless Drill

6" #2 Square Drive Bit



**STEP 1:** (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. **Be careful to not over tighten any of the fasteners.**



(a)

**STEP 2:** (b) (x2) Place one of the side assemblies on a clean soft surface, then place the ottoman top into the mortises and secure with the pre-loaded stainless screws. (c) Secure the side rail to the side assembly thru the predrilled holes using the 1 ½" stainless steel pan head screws provided.



(b)



(c)

