

Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

CROFT END TABLE

Tools Needed

Cordless Drill

6" #2 Square Drive Bit



(a)

STEP 1: (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**

STEP 2: (b) (x4) Slide the legs onto the table skirts (c) Firmly hold the legs in place then fasten them with the 1 ½” stainless steel round head screws provided.



(b)



(c)

