

Installation Instructions

E.C. Woods, Inc. Outdoor Furniture

FREEPORT UMBRELLA SUPPORT

Tools Needed

Cordless Drill

3" #2 Square Drive Bit



(a)

STEP 1: (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**

STEP 2: Place your table upside down on a smooth soft surface such as cardboard or carpet to help avoid scratching. (b,c) Center the Umbrella Support on the bottom side of your table. (d) Fasten using the 1 ½” stainless steel flat head screws provided thru the predrilled holes. (e) Fasten the umbrella support braces to the table top supports by using the 1 ½” stainless steel pan head screws provided thru the pocket holes in the braces and to the Umbrella Support by using the 2” stainless steel flat head screws provided thru the predrilled holes.



(b)



(c)



(d)



(e)

