

Installation Instructions

E.C. Woods, Inc. Outdoor Furniture

UMBRELLA SUPPORT

Tools Needed

Cordless Drill

6" #2 Square Drive Bit



(a)

STEP 1: (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**

STEP 2: Place your table upside down on a smooth soft surface such as cardboard or carpet to help avoid scratching. (b,c) Center the Umbrella Support on the bottom side of your table. (d) Fasten using the 1 ½” flat head stainless steel screws provided thru the predrilled holes. (e) Fasten the umbrella support braces to the table top supports by using the 1 ½” pan head stainless steel screws provided thru the pocket holes in the braces.



(b)



(c)



(d)



(e)

