

# Installation Instructions

E.C. Woods, Inc. Outdoor Furniture

## PORT ROYAL UMBRELLA CLAMP

### Tools Needed

Cordless Drill

6" #2 Square Drive Bit



(a)



(b)

**STEP 1:** Be careful to not over tighten any of the fasteners. (a) Place the umbrella clamp over the aluminum frame with the wing nuts facing away from the center of the table. (b) Secure the umbrella clamp with 1 ½" pan head stainless steel screws.



[ecwoutdoorfurniture.com](http://ecwoutdoorfurniture.com)