

Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

SHAWNEE/CONTEMPORARY

Tools Needed

Cordless Drill

6" #2 Square Drive Bit



STEP 1: (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**

STEP 2: (b) Use a soft hammer (if necessary) to insert the seat skirts and stretchers in to the mortises in the Side Assembly making sure that the screw pockets in the seat skirts are facing up. (c) Place the other Side Assembly on top of the subassembly, with the mortises facing down, and then line the seat skirts and stretchers up with the mortises in the Side Assembly and gently pound them in using your hand or a soft hammer. Fasten the stretchers with the 2" stainless steel flat head screws and the seat skirts with the 1½" round head stainless steel screws provided. Carefully flip the assembly over and do the same to the other side.



(b)



(c)

STEP 3: (OPT ARMS) (d) Fasten the arm supports to the arms using the 1½" stainless steel round head screws provided. Make sure that the returns on the arm and arm support are pointed in the same direction and that the screw pockets on the arm support is facing towards the long portion of the arm. (e) Attach the arm to the chair back leg thru the pre drilled hole in the back leg to the pre drilled hole in the side of the arm using the 2" stainless steel flat head screws provided. (f) Line the bottom of the arm support return up with the top of the radius of the side skirt. (g) Use the 2" stainless steel flat head screws provided to attach the arm support to the seat skirt thru the pre drilled holes.



(d)



(e)



(f)



(g)

STEP 4: (h) Stand the assembled chair up and loosen the screws in one side of the rear seat skirt to aid in inserting the chair back assembly. (i) Insert the chair back assembly in to the mortises in the chair back legs and fasten using the 1½" stainless steel round head screws provided. (j) Tighten the screws that were loosened in (h). (j) Put the seat assembly in place with the straight edge to the front. (k) Make sure that the seat is tight to the seat skirts. (l) Fasten the seat to the rear seat skirt using the 1½" stainless steel round head screws provided. (m) Fasten the sides of the seat assembly to the side skirts using the 1¼" stainless steel flat head screws provided.



(h)



(i)



(j)



(k)



(l)



(m)

