

Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

ST. CROIX TABLE

Tools Needed

Cordless Drill

6" #2 Square Drive Bit

Tape Measure



STEP 1: (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**

STEP 2: (b) Place the stretchers into the mortises of a Leg Assembly. (c) Fasten the stretchers with the 3" stainless steel flat head screws provided. (d) Place the other Leg Assembly on to the stretchers and fasten with the 3" stainless steel flat head screws provided. (e) Center the umbrella support between the bottoms of the stretchers and fasten using the 1/2" stainless steel round head screws provided.



(b)



(c)



(d)



(e)

STEP 3: (f) Place the table top upside down on a soft clean surface then center the table base on the table top. (g) Fasten the table base to the table top with the 1¼" stainless steel round head screws provided thru the pre drilled holes in the aluminum frame.



(f)



(g)

