

Installation Instructions

E.C. Woods, Inc. Outdoor Furniture

UMBRELLA SUPPORT

Tools Needed

Cordless Drill

6" #2 Square Drive Bit



(a)

STEP 1: (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**



(b)



(c)

STEP 2: (b) Place your table upside down on a smooth soft surface such as cardboard or carpet to help avoid scratching. Center the Umbrella Support on the bottom side of your table. (c) Fasten using the 1 ¼" flat head stainless steel screws provided thru the predrilled holes.



(d)



(e)

STEP 3: (d) Fasten the Umbrella Support brace to the aluminum table frame thru the predrilled holes using the 1 ¼" round head stainless steel screws provided making sure that the brace is tight against the Umbrella Support top piece. (e) Fasten the Umbrella Support braces to the Umbrella Support using the 2" flat head stainless steel screws provided thru the predrilled holes.



ecwoutdoorfurniture.com