

Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

WELLS/WILMINGTON ADIRONDACK

Tools Needed

Cordless Drill

6" #2 Square Drive Bit

5/32" Allen Wrench

7/16" Wrench



STEP 1: Lay all pieces on smooth, soft surface, such as cardboard, to avoid scratching. **Be careful to not over tighten any of the fasteners.**



STEP 2: (a) (x2) Secure the front leg assembly to the arm rest using 4 - 1 ½" stainless steel flat head screws (making sure that the bottom of the leg is angled towards the front of the arm rest). (b) (x2) Place the 3 - 3" stainless steel allen head bolts thru the holes in a front leg and line it up with the holes in the back leg (making sure that the front of the arm is towards the front of the chair). (c) (x2) Place the stainless steel lock nuts and washers onto the bolts and secure the front leg to the back leg. (d) Place the back assembly into the recess in the back leg assembly.



(a)



(b)



(c)



(d)

STEP 3: (e) (x2) Line up the side of the back assembly with the outside of the back leg assembly then secure it thru the predrilled holes with 2 – 2” stainless steel flat head screws. (f) (x2) Place a 3 ½” stainless steel allen head bolt thru the predrilled hole in one of the arms and line it up with the predrilled hole in the side back support and secure with stainless steel lock nuts and washers.



(e)



(f)

