

# Assembly Instructions


E.C. Woods, Inc. Outdoor Furniture

## MITCHELL END TABLE

### Tools Needed

Cordless Drill

6" #2 Square Drive Bit



(a)

**STEP 1:** (a) Lay all pieces on a smooth soft surface such as cardboard or carpet to help avoid scratching. We suggest using a 6" #2 square drive bit to fasten all screws (available at your local hardware store). **Be careful to not over tighten any of the fasteners.**

**STEP 2:** (b) (x4) Insert the table legs into the mortises in the table top at an angle away from the table support and pull it towards the support until it is tight. (c) Make sure to line the legs up with the table supports side to side.



(b)



(c)

**STEP 3:** (d) (x4) Secure the legs to the table supports using the 1 1/2" stainless steel screws provided. (e) Insert the bottom shelf by lining the shelf supports up with the mortises in the legs and rotating it into place making sure to line the shelf supports up with the legs side to side.



(d)



(e)

**STEP 4:** (f) Line the boards in the bottom shelf up with the boards in the table top. (g) Secure the shelf supports to the table legs using the 1 ½" stainless steel screws provided.



(f)



(g)



[ecwoutdoorfurniture.com](http://ecwoutdoorfurniture.com)