

Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

SINGLE GLIDER

Tools Needed

Cordless Drill

6" #2 Square Drive Bit

5/32" Allen Wrench

7/16" Wrench

Tape Measure



STEP 1: Lay all pieces on smooth, soft surface, such as cardboard, to avoid scratching. **Be careful to not over tighten any of the fasteners.**



STEP 2: (a) Secure the leg assembly to the seat using 3" stainless steel allen head bolts through the predrilled holes in the leg assembly and seat (making sure that the wider end of the arm rest is towards the front of the seat). (b) Place a stainless steel washer and lock nut on the back of the bolt and tighten until the head of the bolt sits tight to the leg. (c) Fasten the back assembly to the seat by using 2 1/2" stainless steel lags through the pre drilled holes in the seat support and back bottom support. (d) Fasten the arms by using 3 1/2" stainless steel lags through the predrilled holes in the arm and middle back support.



(a)



(b)



(c)




(d)


STEP 3: (e) Fasten the glider base spreaders to the glider base sides by using 1 ½" stainless steel pan head screws (making sure to face the pocket holes towards the middle). **(see step 4 for balcony height)** (f) Fasten the stops to the base assembly by using 2 ½" allen head stainless steel bolts thru the predrilled holes in the stop and the base assembly (making sure to use the holes closest to the middle of the glider base) and place a stainless steel washer and lock nut on the inside and tighten. (g) Fasten the glider bracket to the base by using 2" allen head stainless steel bolts thru the bracket (making sure the bracket offsets towards the outside of the base), ¼" spacer, and predrilled hole in the base, then place a stainless steel washer and lock nut on the inside and tighten. (h) Fasten the chair to the base by using 2 ¼" allen head stainless steel bolts through the predrilled holes in the side stretcher and glider bracket then place a stainless steel lock nut on the back of the bolt and tighten.



(e)



(f)



(g)



(h)

STEP 4: (i) Place the glider base side in to the pocket in the footrest. (j) Fasten the footrest to the base assembly by using 1 ½” stainless steel pan head screws through the pocket holes in the base assembly.



(i)



(j)

