

# Assembly Instructions

E.C. Woods, Inc. Outdoor Furniture

## EZ GLIDE SWIVEL GLIDER


### Tools Needed

5/32" Allen Wrench

7/16" Wrench




**STEP 1:** Lay all pieces on smooth, soft surface, such as cardboard, to avoid scratching. Be careful to not over tighten any of the fasteners.



**STEP 2:** (a) (x2) Secure the leg assembly to the seat using 2 - 3" stainless steel allen head bolts through the predrilled holes in the leg assembly and seat (making sure that the wider end of the arm rest is towards the front of the seat). (b) Place a stainless steel washer and lock nut on the back of the bolt and tighten until the head of the bolt sits tight to the leg. (c) (x2) Fasten the back assembly to the seat by using 1 - 2 1/2" stainless steel lag and to the arm by using 1 - 3 1/2" stainless steel lag through the predrilled holes. (d) The chair is ready to be attached to the swivel assembly.



(a)



(b)




(c)



(d)

**STEP 3:** (e) Remove the glider/swivel base from the box and place it on your work surface making note that one end is longer than the other. (f) Place the chair assembly on top of the base with the back of the chair towards the longer end. (g) (x4) Starting with the back place a 2 ½" allen head stainless steel bolt thru the predrilled hole in the leg, the ¼" spacer, and the glider bracket. (h) (x4) Place a stainless steel lock nut on the back of the bolt and tighten.



(e)



(f)



(g)



(h)

